


SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices


DEREK HOLZER
STOCKHOLM FEB 2022



SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



PLEASE REFER TO DOCUMENTATION OF
THE ORIGINAL MODULES FOR DETAILS

SCAN PROCESSOR
BLOCK DIAGRAM


Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022

USE FOR:

HORIZONTAL
VERTICAL
DEPTH
(BIPOLAR)

BRIGHTNESS
(UNIPOLAR,
NO SIZE CV)



SECTION TOTAL

1 * multiplier
3 * summers


MULTIPLIER = 4 QUAD (BIPOLAR)
1 QUAD (UNIPOLAR)

SECTION II : SIZE & POSITION

SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



SECTION TOTAL

12 * multipliers
21 * summers


CV sin/cos input for quadrature oscillator or manual rotation (digital source might be easiest).
Offsets on axes shift center of rotation. Offsets on CV inputs convert 0-1V unipolar to +/- 0.5V bipolar.
Order of rotations can be re-patched

SECTION IIIa : ROTATION

SCAN PROCESSOR BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate, and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



PER AXIS TOTAL

4 * multipliers
7 * summers


ALL MULTIPLIERS = 4 QUAD
CV inputs must be offset to +/- 0.5V

SECTION IIIb : ONE AXIS ROTATOR

SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022




PLEASE REFER TO DOCUMENTATION OF
THE ORIGINAL MODULES FOR DETAILS

SECTION IV : OSCILLATORS

SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



SECTION TOTAL

3 * multipliers
7 * summers

PERSPECTIVE

$$H_{out} = H_{in} / D - \text{ViewingDistance}$$
$$V_{out} = V_{in} / D - \text{ViewingDistance}$$

(Viewing angle not factored in)

INTENSITY


$$B_{out} = B_{bin} * (\text{ShadowPoint} - D / \text{ShadowPoint})$$

SECTION V : PERSPECTIVE

SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



SECTION TOTAL

1 * summers


SIMPLE SCALING OP-AMP
SEE LZX CADET V SCALER FOR DETAILS

SECTION VI: LEVEL SHIFT

SCAN PROCESSOR
BLOCK DIAGRAM

Combining elements of the Rutt/Etra, Scanimate,
and Optical Electronics Inc devices

DEREK HOLZER
STOCKHOLM FEB 2022



SECTION TOTAL

18 * summers =
scaling op-amp buffers

ALL INPUTS SCALED +/-5V to 0 - 1V. ALL OUTPUTS 0 - 1V.
AUDIO RATE I/O DEPENDING ON TEENSY ADC + DAC
JOYSTICK INCREMENTAL RATHER THAN CONTINUOUS
JOYSTICK CV SUMMED WITH CV_{in} AFTER DIGITIZATION
RESET BUTTON FOR JOYSTICK INCREMENTS

SECTION VII: 3D JOYSTICK CONTROL